

## **Rocker Switches & Push Button Switches**



## **PUSH BUTTON DOOR SWITCH (WITH BOOT)**

\*765212

\*765212 2-Positions (ON-OFF, OFF with Plunger depressed, Spring return to ON).
S.P.S.T., 4A @ 12VDC Lamp load. Two 2mm x 5mm Blade Terminals.
Plastic Button, Black Rubber Boot protects the face of the Switch.
Similar to p# 9006

